Technical support: support@abbkine.com

Website: https://www.abbkine.com

# CheKine™ Mirco Soluble Pectin (WSP) Content Assay Kit

Cat #: KTB1583 Size: 48 T/96 T

| FQ  | Mirco Soluble Pectin (WSP) Content Assay Kit              |     |                               |
|-----|---|-----|-------------------------------|
| REF | Cat #: KTB1583  | LOT | Lot #: Refer to product label |
|     | Applicable sample: Plant Tissues                          |     |                               |
| Ŷ   | Storage: Stored at 4°C for 6 months, protected from light |     |                               |

### **Assay Principle**

Pectin is a major component of the primary cell wall and middle lamella, primarily consisting of protopectin, pectic acid methylester, and pectic acid. Pectin contains galacturonic acid, galactose, arabinose, glucuronic acid, and others, making it one of the most abundant polysaccharides in the cell walls of many higher plants. Its unique physical and chemical properties affect the texture and quality of plant-derived foods. Pectins are cross-linked by Ca²+ bridges and other ionic bonds, hydrogen bonds, glycosidic bonds, ester bonds, and phenolic ring couplings. Various forms of pectin can be extracted through different extraction methods, such as water-soluble pectin (WSP), ionically-bound pectin (ISP), and covalently-bound pectin (CSP). CheKine™ Mirco Soluble Pectin (WSP) Content Assay Kit provides a simple, convenient, and rapid method for WSP content determination suitable for plant tissue samples. The principle involves using an acidic solution to extract soluble pectin (WSP), followed by quantification using the carbazole colorimetric method. Pectin is hydrolyzed into galacturonic acid, which reacts with carbazole reagent in sulfuric acid solution to form a compound with maximum absorbance at 530 nm.

## **Materials Supplied and Storage Conditions**

|                |           | Size   |                           |  |
|----------------|-----------|--------|---------------------------|--|
| Kit components | 48 T 96 T |        | Storage conditions        |  |
| Reagent        | 50 mL     | 100 mL | 4°C                       |  |
| Reagent II     | 50 mL     | 100 mL | 4℃                        |  |
| Reagent III    | 2.5 mL    | 5 mL   | 4℃                        |  |
| Standard       | 1 mL      | 1 mL   | 4°C, protected from light |  |

### **Materials Required but Not Supplied**

- · Microplate reader or visible spectrophotometer capable of measuring absorbance at 530 nm
- Incubator, analytical balance, ice maker, freezing centrifuge
- 96-well plate or microglass cuvette, precision pipettes, disposable pipette tips



Version 20240830

- · Deionized water, 80% ethanol, acetone, concentrated sulfuric acid
- · Dounce homogenizer

#### **Reagent Preparation**

Reagent I: Ready to use as supplied. Equilibrate to room temperature before use. Store at 4°C.

Reagent II: Ready to use as supplied. Equilibrate to room temperature before use. Store at 4°C.

Reagent III: Ready to use as supplied. Equilibrate to room temperature before use. Store at 4°C.

Standard: Ready to use as supplied. Equilibrate to room temperature before use. Store at 4°C, protected from light.

### **Sample Preparation**

Note: We recommend that you use fresh samples. If not assayed immediately, samples can be stored at -80°C for one month. When measuring, the temperature and time of thawing should be controlled. When thawing at room temperature, the sample should be thawed within 4 h.

- 1. Extract the cell wall: Weigh approximately 0.3 g of the sample, add 1 mL of 80% ethanol, and homogenize quickly at room temperature. Incubate in a 95°C water bath for 20 min, then cool to room temperature. Centrifuge at 4,000 g at 25°C for 10 min and discard the supernatant. Wash the pellet once with 1.5 mL of 80% ethanol and once with acetone (vortex for about 2 min, centrifuge at 4,000 g at 25°C for 10 min, and discard the supernatant). The resulting pellet is the crude cell wall. Add 1 mL of Reagent I (to remove starch) and soak for 15 h. Centrifuge at 4,000 g at 25°C for 10 min, discard the supernatant, dry the pellet, and weigh to obtain the cell wall material (CWM).
- 2. WSP Extraction: Weigh 3 mg of dried CWM and add 1 mL of Reagent II. Homogenize thoroughly (if the dried material is hard, crush it first before adding 1 mL of Reagent II and homogenizing, or use a homogenizer). Centrifuge at 8,000 g at 4°C for 10 min, and retain the supernatant for analysis.

Note: Acetone has a strong odor and is recommended to be used in a fume hood.

### **Assay Procedure**

- 1. Preheat the microplate reader or visible spectrophotometer for more than 30 min, and adjust the wavelength to 530 nm. Visible spectrophotometer was returned to zero with deionized water.
- 2. Preheat Reagent ||| and Reagent || at 37°C for more than 10 min.
- 3. Operation table (The following operations are operated in the 1.5 mL EP Tube):

| Reagent         | Test Tube (μL) | Control Tube (μL) | Blank Tube (µL) | Standard Tube (µL) |
|-----------------|----------------|-------------------|-----------------|--------------------|
| Sample          | 50             | 50                | 0               | 0                  |
| Standard        | 0              | 0                 | 0               | 50                 |
| Deionized Water | 0              | 50                | 50              | 0                  |
| Reagent III     | 50             | 0                 | 50              | 50                 |
|                 |                |                   |                 |                    |

Mix well

| Concentrated Sulfuric | 400 | 400 | 400 | 400 |
|-----------------------|-----|-----|-----|-----|
| Acid                  | 400 | 400 | 400 | 400 |

Mix well and incubate in a 95°C water bath for 5 min, and then cool. Transfer 200  $\mu$ L to a microglass cuvette or a 96-well plate, and measure the absorbance at 530 nm, recording them as  $A_{Test}$ ,  $A_{Control}$ ,  $A_{Blank}$  and  $A_{Standard}$ , respectively. Calculate  $\Delta A_{Test} = A_{Test} - A_{Control}$ ,  $\Delta A_{Standard} = A_{Standard} - A_{Blank}$ .

Note: (1) Before the experiment, it is suggested that 2-3 samples with large expected differences should be selected for pre-experiment. The Standard Tube and Blank Tube need to be prepared only 1-2 times, while each Test Tube requires a corresponding Control Tube. If A<sub>Test</sub> is greater than 2, the sample to be tested needs to be diluted with deionized water



Version 20240830

(can be diluted 10 or 20 times). (2) Concentrated sulfuric acid is highly corrosive, so please take proper precautions and handle with care.

### **Data Analysis**

Note: We provide you with calculation formulae, including the derivation process and final formula. The two are exactly equal. It is suggested that the concise calculation formula in bold is final formula.

Calculation of WSP content:

 $WSP (mg/g \ dry \ weight) = (C_{Standard} \times V_1) \times \Delta A_{Test} + \Delta A_{Standard} + (W \times V_1 + V_2) \times F = \textbf{0.05} \times \Delta A_{Test} + \Delta A_{Standard} + W \times F + \Delta A_{Standard} + W \times F + \Delta A_{Standard} + W \times F + \Delta A_{Standard} + \Delta A_{St$ 

Where:  $C_{Standard}$ : Concentration of Standard; 0.05 mg/mL;  $V_1$ : sample volume added to the reaction system, 0.05 mL;  $V_2$ : Extraction Buffer volume added, 1 mL; W: sample dry weight, g.

#### **Precautions**

1. The minimum detection limit is 50  $\mu$ g/g dry weight.

## **Typical Data**




Figure 1. Determination WSP activity in Apple pulp and Grape skin by this assay kit

## **Recommended Products**

| Catalog No. | Product Name                                       |  |
|-------------|--|--|
| KTB1015     | CheKine™ Micro α-Glucosidase Activity Assay Kit    |  |
| KTB1121     | CheKine™ Pyruvate Acid (PA) Colorimetric Assay Kit |  |

### **Disclaimer**

The reagent is only used in the field of scientific research, not suitable for clinical diagnosis or other purposes.

